




Parts List



a) front wheels
b) top wing
c) bottom wing
d) rear wheels
e) window


f) propeller
g) motor grill
h) upper body
i) under body
j) rear wings

k) chassis
l) bolts
m) nuts



⚠ WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

battat®



REPLACING BATTERIES

2 x AA (1.5v) batteries Not Included

Non-rechargeable batteries are not to be recharged.

Rechargeable batteries are to be removed from the toy before being charged.

Rechargeable batteries are only to be charged under adult supervision.

Different types of batteries or new and used batteries are not to be mixed.

Only batteries of the same or equivalent type as recommended are to be used.

Batteries are to be inserted with the correct polarity.

Exhausted batteries are to be removed from the toy.

The supply terminals are not to be short-circuited.

childhood is magical™