


CATALOGUE 2021





How many princesses will attend the party? And who says a tiara doesn't go well with a chef's apron? Then it's off to the grocery store! Are you the customer or the clerk today? Either way, it's always better to show up with a skip in your step and without a wrinkle in your clothes. Be sure to get home in time to tidy up for a musical tea party or a midnight ice cream feast.

Play Circle. Play the day away.



















1 PC2211C1Z

34.3cm x 27cm x 40cm set. Includes 29 assorted food items in a shopping cart.

Case Pack: 2

UPC: 0 62243 28677 1

2 PC2236Z

33cm x 35.6cm set. Case Pack: 6/24 UPC: 0 62243 28676 4

3 PC2210Z

23.9cm x 15.8cm x 29cm set. Includes 79 assorted food items in a bucket.

Case Pack: 2

UPC: 0 62243 28679 5

4 PC2225Z

33.5cm x 19.5cm x 13.2cm Includes 21 pieces. Case Pack (pcs): 2

UPC: 0 62243 28680 1

5PC2219Z

25.4cm x 8.9cm x 30.5cm Includes 34 pieces. Case Pack (pcs): 4

UPC: 0 62243 28682 5















1 PC2221Z

29.4cm x 15.2cm x 24cm Includes tea pot with sounds and 16 other pieces.

Case Pack (pcs): 2 UPC: 0 62243 28684 9

2 PC2216Z

24cm x 6.4cm x 40.6cm Includes 21 pieces. Case Pack (pcs): 2 UPC: 0 62243 28674 0

3 PC2215Z

24cm x 6.4cm x 40.6cm Includes 24 pieces. Case Pack (pcs): 2 UPC: 0 62243 28673 3

4 PC2222Z

61cm x 11.4cm x 25.4cm Includes a vacuum with realistic sound and a removable hand vac.

Case Pack (pcs): 2 UPC: 0 62243 28685 6

5 PC2223Z

61cm x 10.2cm x 25.4cm Includes 3 pieces. Case Pack (pcs): 2

UPC: 0 62243 28686 3

6 PC2239Z

20cm x 5cm x 81cm Includes 4 pieces. Case Pack (pcs): 4 UPC: 0 62243 28671 9

6

PLAYCIRCLE





1 PC2230Z

25.4cm x 19.5cm x16.5cm Includes 7 pieces. Case Pack (pcs): 4 UPC: 0 62243 28678 8 2PC2008Z

25.4cm x 10.8cm x 26.67cm Includes 15 pieces. Case Pack (pcs): 2 UPC: 0 62243 25700 9 3 PC2227Z

25.4cm x 5cm x 40.6cm Includes 24 pieces. Case Pack (pcs): 2 UPC: 0 62243 28669 6



