PLAYCIRCLE® CATALOGUE 2021

PRINCESS



play the day How many princesses will attend the party? And who says a tiara doesn't go well with a chef's apron? Then it's off to the grocery Store! Are you the customer or the clerk today? Either way, it's always better to show up with a skip in your Step and without a wrinkle in your clothes. Be Sure to get home in time to tidy up for a musical tea party or a midnight ice cream feast. Play Circle. Play the day away.





DISHES WISHES DINNERWARE



PC2211C1Z

34.3cm x 27cm x 40cm set. Includes 29 assorted food items in a shopping cart. Case Pack: 2 UPC: 0 62243 28677 1

2 PC2236Z 33cm x 35.6cm set.

33cm x 35.6cm set. Case Pack: 6/24 UPC: 0 62243 28676 4

y A b V b

³ PC2210Z

23.9cm x 15.8cm x 29cm set. Includes 79 assorted food items in a bucket. Case Pack: 2 UPC: 0 62243 28679 5 PC2225Z 33.5cm x 19.5cm x 13.2cm Includes 21 pieces. Case Pack (pcs): 2 UPC: 0 62243 28680 1 DC2219Z
25.4cm x 8.9cm x 30.5cm
Includes 34 pieces.
Case Pack (pcs): 4
UPC: 0 62243 28682 5





29.4cm x 15.2cm x 24cm Includes tea pot with sounds and 16 other pieces. Case Pack (pcs): 2 UPC: 0 62243 28684 9

2 PC2216Z

24cm x 6.4cm x 40.6cm Includes 21 pieces. Case Pack (pcs): 2 UPC: 0 62243 28674 0

3 PC2215Z

24cm x 6.4cm x 40.6cm Includes 24 pieces. Case Pack (pcs): 2 UPC: 0 62243 28673 3

PC2222Z

61cm x 11.4cm x 25.4cm Includes a vacuum with realistic sound and a removable hand vac. Case Pack (pcs): 2 UPC: 0 62243 28685 6

DC2223Z 61cm x 10.2cm x 25.4cm Includes 3 pieces.

Includes 3 pieces. Case Pack (pcs): 2 UPC: 0 62243 28686 3

6 PC2239Z 20cm x 5cm x 81cm Includes 4 pieces. Case Pack (pcs): 4 UPC: 0 62243 28671 9

PLAYCIRCLE



DPC2230Z

25.4cm x 19.5cm x16.5cm Includes 7 pieces. Case Pack (pcs): 4 UPC: 0 62243 28678 8

2 PC2008Z 25.4cm x 10.8cm x 26.67cm

25.4cm x 10.8cm x 26.67cm Includes 15 pieces. Case Pack (pcs): 2 UPC: 0 62243 25700 9

³PC2227Z

25.4cm x 5cm x 40.6cm Includes 24 pieces. Case Pack (pcs): 2 UPC: 0 62243 28669 6



